

RTA

CABINET STORE

June 21, 2026

Natural Hickory Shaker Kitchen Cabinets Price List



Sink base

| Model # | Item | Price |
|----------|--|----------|
| SH-FSB36 | Shaker Hickory Farm Sink Base Cabinet - 36" W | \$454.12 |
| SH-SB30 | Shaker Hickory Sink Base Cabinet - 30" W x 34.5" H | \$347.26 |
| SH-SB33 | Shaker Hickory Sink Base Cabinet - 33" W x 34.5" H | \$367.86 |
| SH-SB36 | Shaker Hickory Sink Base Cabinet - 36" W x 34.5" H | \$377.88 |

Microwave

| Model # | Item | Price |
|------------|---|----------|
| SH-MBC30 | Shaker Hickory Microwave Base Cabinet - 30" W | \$445.22 |
| SH-MWC3018 | Shaker Hickory Microwave Wall Cabinet 18" H x 30" W x 12" D | \$159.17 |

Filler

| Model # | Item | Price |
|---------|--------------------------------------|----------|
| SH-F342 | Shaker Hickory Filler - 3" W x 42" H | \$28.38 |
| SH-F396 | Shaker Hickory Filler - 3" W x 96" H | \$53.44 |
| SH-F642 | Shaker Hickory Filler - 6" W x 42" H | \$56.76 |
| SH-F696 | Shaker Hickory Filler - 6" W x 96" H | \$106.85 |

End panel

| Model # | Item | Price |
|-------------|---|----------|
| SH-BPLG4896 | Shaker Hickory Back Panel (Long Grain) - 48" W x 96" H | \$187.56 |
| SH-DWR3 | Shaker Hickory Dish Washer End Panel | \$114.64 |
| SH-OP3353 | Shaker Hickory Oven Cabinet Overlay Panel - 33" W x 55" H | \$140.79 |
| SH-TEP3096 | Shaker Hickory Tall End Panel | \$256.57 |

Molding

| Model # | Item | Price |
|---------|--|---------|
| SH-BEM8 | Shaker Hickory Bottom Edge Molding (Narrow Light Rail) | \$67.89 |

| | | |
|---------|---------------------------------------|----------|
| SH-OCM8 | Shaker Hickory Outside Corner Molding | \$25.06 |
| SH-SHOE | Shaker Hickory Shoe Molding | \$20.60 |
| SH-SCM8 | Shaker Hickory Shaker Crown Molding | \$66.79 |
| SH-COM8 | Shaker Hickory Cove Crown Molding | \$141.92 |
| SH-FBM8 | Shaker Hickory Furniture Base Molding | \$94.06 |

Blind door

| Model # | Item | Price |
|---------|--|----------|
| SH-BB36 | Shaker Hickory Blind Base Cabinet for 36" to 39" Space - 30" W | \$459.70 |
| SH-BB42 | Shaker Hickory Blind Base Cabinet for 42" to 45" Space - 36" W | \$520.92 |
| SH-BB48 | Shaker Hickory Blind Base Cabinet for 48" to 51" Space - 48" W | \$573.22 |

Pantry

| Model # | Item | Price |
|----------|---------------------------------------|------------|
| SH-P1884 | Shaker Hickory Pantry - 18" W x 84" H | \$719.58 |
| SH-P1890 | Shaker Hickory Pantry - 18" W x 90" H | \$776.36 |
| SH-P2484 | Shaker Hickory Pantry - 24" W x 84" H | \$890.99 |
| SH-P2490 | Shaker Hickory Pantry - 24" W x 90" H | \$920.48 |
| SH-P3090 | Shaker Hickory Pantry - 30" W x 90" H | \$1,083.01 |

Oven

| Model # | Item | Price |
|-----------|---|------------|
| SH-OC3390 | Shaker Hickory Oven Cabinet - 33" W x 90" H | \$1,167.04 |
| SH-OCD337 | Shaker Hickory Oven Cabinet Drawer | \$302.18 |

Single door

| Model # | Item | Price |
|----------|--|----------|
| SH-B09 | Shaker Hickory Single Door Full Height Base Cabinet - 9" W | \$199.80 |
| SH-B12 | Shaker Hickory Single Door Standard Base Cabinet - 12" W | \$274.90 |
| SH-B15 | Shaker Hickory Single Door Standard Base Cabinet - 15" W | \$299.98 |
| SH-B18 | Shaker Hickory Single Door Standard Base Cabinet - 18" W | \$323.34 |
| SH-B21 | Shaker Hickory Single Door Standard Base Cabinet - 21" W | \$349.49 |
| SH-W1230 | Shaker Hickory Single Door Wall Cabinet - 12" W x 30" H | \$159.17 |
| SH-W1236 | Shaker Hickory Single Door Wall Cabinet - 12" W x 36" H | \$179.19 |
| SH-W1242 | Shaker Hickory Single Door Wall Cabinet - 12" W x 42" H | \$213.70 |
| SH-W1530 | Shaker Hickory Single Door Wall Cabinet - 15" W x 30" H | \$178.10 |
| SH-W1536 | Shaker Hickory Single Door Wall Cabinet - 15" W x 36" H | \$205.36 |
| SH-W1542 | Shaker Hickory Single Door Wall Cabinet - 15" W x 42" H | \$243.21 |
| SH-W1830 | Shaker Hickory Single Door Wall Cabinet - 18" W x 30" H | \$204.25 |
| SH-W1836 | Shaker Hickory Single Door Wall Cabinet - 18" W x 36" H | \$232.64 |
| SH-W1842 | Shaker Hickory Single Door Wall Cabinet - 18" W x 42" H | \$277.17 |
| SH-W2130 | Shaker Hickory Single Door Wall Cabinet - 21" W x 30" H | \$228.16 |
| SH-W2136 | Shaker Hickory Single Door Wall Cabinet - 21" W x 36" H | \$259.91 |
| SH-W2142 | Shaker Hickory Single Door Wall Cabinet - 21" W x 42" H | \$308.87 |
| SH-W930 | Shaker Hickory Single Door Wall Cabinet - 9" W x 30" H | \$138.58 |
| SH-W936 | Shaker Hickory Single Door Wall Cabinet - 9" W x 36" H | \$156.93 |
| SH-W942 | Shaker Hickory Single Door Wall Cabinet - 9" W x 42" H | \$186.44 |

Double door

| Model # | Item | Price |
|----------|---|----------|
| SH-V24-2 | Shaker Hickory Double Door Vanity - 24" W x 34.5" H x 21" D | \$266.57 |

| | | |
|------------|---|----------|
| SH-V27 | Shaker Hickory Double Door Vanity - 27" W x 34.5" H x 21" D | \$311.11 |
| SH-V30 | Shaker Hickory Double Door Vanity - 30" W x 34.5" H x 21" D | \$322.24 |
| SH-W2430-2 | Shaker Hickory Double Door Wall Cabinet - 24" W x 30" H | \$271.60 |
| SH-W2436-2 | Shaker Hickory Double Door Wall Cabinet - 24" W x 36" H | \$316.66 |
| SH-W2442-2 | Shaker Hickory Double Door Wall Cabinet - 24" W x 42" H | \$365.65 |
| SH-W2730 | Shaker Hickory Double Door Wall Cabinet - 27" W x 30" H | \$303.32 |
| SH-W2736 | Shaker Hickory Double Door Wall Cabinet - 27" W x 36" H | \$342.83 |
| SH-W2742 | Shaker Hickory Double Door Wall Cabinet - 27" W x 42" H | \$407.37 |
| SH-W3012 | Shaker Hickory Double Door Wall Cabinet - 30" W x 12" H | \$141.92 |
| SH-W3015 | Shaker Hickory Double Door Wall Cabinet - 30" W x 15" H | \$175.88 |
| SH-W3018 | Shaker Hickory Double Door Wall Cabinet - 30" W x 18" H | \$227.08 |
| SH-W3021 | Shaker Hickory Double Door Wall Cabinet - 30" W x 21" H | \$249.88 |
| SH-W3024 | Shaker Hickory Double Door Wall Cabinet - 30" W x 24" H | \$278.26 |
| SH-W3030 | Shaker Hickory Double Door Wall Cabinet - 30" W x 30" H | \$313.31 |
| SH-W3036 | Shaker Hickory Double Door Wall Cabinet - 30" W x 36" H | \$371.20 |
| SH-W3042 | Shaker Hickory Double Door Wall Cabinet - 30" W x 42" H | \$440.77 |
| SH-W3312 | Shaker Hickory Double Door Wall Cabinet - 33" W x 12" H | \$159.17 |
| SH-W3315 | Shaker Hickory Double Door Wall Cabinet - 33" W x 15" H | \$192.01 |
| SH-W3318 | Shaker Hickory Double Door Wall Cabinet - 33" W x 18" H | \$242.12 |
| SH-W3324 | Shaker Hickory Double Door Wall Cabinet - 33" W x 24" H | \$291.61 |
| SH-W3330 | Shaker Hickory Double Door Wall Cabinet - 33" W x 30" H | \$349.49 |
| SH-W3336 | Shaker Hickory Double Door Wall Cabinet - 33" W x 36" H | \$398.48 |
| SH-W3342 | Shaker Hickory Double Door Wall Cabinet - 33" W x 42" H | \$472.49 |
| SH-W3612 | Shaker Hickory Double Door Wall Cabinet - 36" W x 12" H | \$175.88 |
| SH-W3615 | Shaker Hickory Double Door Wall Cabinet - 36" W x 15" H | \$196.45 |
| SH-W3618 | Shaker Hickory Double Door Wall Cabinet - 36" W x 18" H | \$261.01 |
| SH-W3624 | Shaker Hickory Double Door Wall Cabinet - 36" W x 24" H | \$312.21 |
| SH-W3630 | Shaker Hickory Double Door Wall Cabinet - 36" W x 30" H | \$362.30 |
| SH-W3636 | Shaker Hickory Double Door Wall Cabinet - 36" W x 36" H | \$425.77 |
| SH-W3642 | Shaker Hickory Double Door Wall Cabinet - 36" W x 42" H | \$505.33 |
| SH-W3930 | Shaker Hickory Double Door Wall Cabinet - 39" W x 30" H | \$410.72 |
| SH-W3936 | Shaker Hickory Double Door Wall Cabinet - 39" W x 36" H | \$456.35 |
| SH-W3942 | Shaker Hickory Double Door Wall Cabinet - 39" W x 42" H | \$542.62 |
| SH-W4230 | Shaker Hickory Double Door Wall Cabinet - 42" W x 30" H | \$425.77 |
| SH-W4236 | Shaker Hickory Double Door Wall Cabinet - 42" W x 36" H | \$484.74 |
| SH-W4242 | Shaker Hickory Double Door Wall Cabinet - 42" W x 42" H | \$574.34 |
| SH-B24-2 | Shaker Hickory Double Door/ Single Drawer Standard Base Cabinet - 24" W | \$386.23 |
| SH-B27 | Shaker Hickory Double Door Standard Base Cabinet - 27" W | \$476.96 |
| SH-B30 | Shaker Hickory Double Door Standard Base Cabinet - 30" W | \$490.30 |
| SH-B33 | Shaker Hickory Double Door Standard Base Cabinet - 33" W | \$532.60 |
| SH-B36 | Shaker Hickory Double Door Standard Base Cabinet - 36" W | \$543.73 |
| SH-B39 | Shaker Hickory Double Door Standard Base Cabinet - 39" W | \$555.42 |
| SH-B42 | Shaker Hickory Double Door Standard Base Cabinet - 42" W | \$572.10 |

Lazy susan

| Model # | Item | Price |
|----------|---|----------|
| SH-LSB33 | Shaker Hickory Lazy Susan Cabinet - 33" W x 24" D | \$788.98 |
| SH-LSB36 | Shaker Hickory Lazy Susan Cabinet - 36" W x 24" D | \$829.73 |

Easy reach

| Model # | Item | Price |
|---------|---|----------|
| SH-ER30 | Shaker Hickory Easy Reach Cabinet - 30" W x 24" D | \$788.98 |

| | | |
|---------|--|----------|
| SH-ER33 | Shaker Hickory Easy Reach Base Cabinet - 33" W x 24" D | \$539.28 |
| SH-ER36 | Shaker Hickory Easy Reach Base Cabinet - 36" W x 24" D | \$579.90 |

HiQpdf Evaluation 06/21/2026

Drawer base

| Model # | Item | Price |
|-----------|---|----------|
| SH-DB12-3 | Shaker Hickory Drawer Base Cabinet - 12" W | \$415.72 |
| SH-DB15-3 | Shaker Hickory Drawer Base Cabinet - 15" W | \$459.70 |
| SH-DB18-3 | Shaker Hickory Drawer Base Cabinet - 18" W | \$493.65 |
| SH-DB21-3 | Shaker Hickory Drawer Base Cabinet - 21" W | \$528.15 |
| SH-DB24-3 | Shaker Hickory Drawer Base Cabinet - 24" W | \$564.31 |
| SH-DB27-3 | Shaker Hickory Drawer Base Cabinet - 27" W | \$603.85 |
| SH-DB30-3 | Shaker Hickory Drawer Base Cabinet - 30" W | \$643.92 |
| SH-DB33-3 | Shaker Hickory Drawer Base Cabinet - 33" W | \$683.42 |
| SH-DB36-3 | Shaker Hickory Drawer Base Cabinet - 36" W | \$722.93 |
| SH-VDB12 | Shaker Hickory Vanity Drawer Base - 12" W x 34.5" H x 21" D | \$408.47 |
| SH-VDB15 | Shaker Hickory Vanity Drawer Base - 15" W x 34.5" H x 21" D | \$441.87 |
| SH-VDB18 | Shaker Hickory Vanity Drawer Base - 18" W x 34.5" H x 21" D | \$475.84 |
| SH-VDB24 | Shaker Hickory Vanity Drawer Base - 24" W x 34.5" H x 21" D | \$552.62 |

Other

| Model # | Item | Price |
|--------------|--|----------|
| SH-VSBDL30 | Shaker Hickory Vanity Combo Cab - Drw Left - 30" W x 21" D | \$482.53 |
| SH-VSBDL36 | Shaker Hickory Vanity Combo Cab - Drw Left - 36" W x 21" D | \$569.87 |
| SH-VSBDR30 | Shaker Hickory Vanity Combo Cab - Drw Right - 30" W x 21" D | \$482.53 |
| SH-VSBDR36 | Shaker Hickory Vanity Combo Cab - Drw Right - 36" W x 21" D | \$569.87 |
| SH-SCRIBE | Shaker Hickory Scribe | \$21.71 |
| SH-SHELF1296 | Shaker Hickory Shelf - 96" W x 12" D | \$143.04 |
| SH-SWR3012 | Shaker Hickory Stemware Rack | \$47.87 |
| SH-TKS8 | Shaker Hickory Toe Kick | \$17.25 |
| SH-TRB18FH | Shaker Hickory Trash Can Base w/ Full Height Door - 18" W (Does Not Include Trash Can) | \$606.05 |
| SH-DWR1548 | Shaker Hickory Wall Twr w/ 3 Drws - 15" W x 48" H x 14.5" D | \$516.47 |
| SH-DWR1554 | Shaker Hickory Wall Twr w/ 3 Drws - 15" W x 54" H x 14.5" D | \$544.85 |
| SH-DWR1560 | Shaker Hickory Wall Twr w/ 3 Drws - 15" W x 60" H x 14.5" D | \$590.47 |
| SH-CW2430 | Shaker Hickory Corner Wall Cabinet - 24" W x 30" H | \$340.60 |
| SH-CW2436 | Shaker Hickory Corner Wall Cabinet - 24" W x 36" H | \$382.34 |
| SH-CW2442 | Shaker Hickory Corner Wall Cabinet - 24" W x 42" H | \$484.74 |
| SH-CW2736 | Shaker Hickory Corner Wall Cabinet - 27" W x 36" H | \$436.89 |
| SH-CW2742 | Shaker Hickory Corner Wall Cabinet - 27" W x 42" H | \$518.66 |