

RTA

CABINET STORE

April 04, 2026

Primary White Shaker Kitchen Cabinets Price List



Sink base

Model #	Item	Price
EW-CSF42	Primary White Shaker Corner Sink Front for 42" Space - 27" W	\$152.65
EW-SB30	Primary White Shaker Sink Base Cabinet - 30" W x 34.5" H	\$274.50
EW-SB33	Primary White Shaker Sink Base Cabinet - 33" W x 34.5" H	\$290.79
EW-SB36	Primary White Shaker Sink Base Cabinet - 36" W x 34.5" H	\$298.70
EW-SB42	Primary White Shaker Sink Base Cabinet w/ CS - 42" W x 34.5" H	\$342.69
EW-VSB36	Primary White Shaker Vanity Sink Base - 36" W x 34.5" H x 21" D	\$410.01
EW-VSB42	Primary White Shaker Vanity Sink Base - 42" W x 34.5" H x 21" D	\$454.00
EW-VSB48	Primary White Shaker Vanity Sink Base - 48" W x 34.5" H x 21" D	\$507.24

Filler

Model #	Item	Price
EW-FF396	Primary White Shaker Fluted Filler - 3" W x 96" H	\$106.46
EW-OLF330	Primary White Shaker Overlay for 3" x 30" Filler	\$37.39
EW-OLF336	Primary White Shaker Overlay for 3" x 36" Filler	\$43.55
EW-OLF342	Primary White Shaker Overlay for 3" x 42" Filler	\$50.14
EW-OLF630	Primary White Shaker Overlay for 6" x 30" Filler	\$75.24
EW-F396	Primary White Shaker Filler - 3" W x 96" H	\$58.94
EW-F696	Primary White Shaker Filler - 6" W x 96" H	\$118.34

End panel

Model #	Item	Price
EW-DWR3	Primary White Shaker Dish Washer End Panel	\$126.71
EW-BPLG4896	Primary White Shaker Back Panel (Long Grain) - 48" W x 96" H x 1/4" Thick	\$208.09
EW-OP3353	Primary White Shaker Oven Cabinet Overlay Panel - 33" W x 55" H	\$155.73
EW-TEP3096	Primary White Shaker Tall End Panel	\$223.03
EW-PSP4896	Primary White Shaker 1/2" Thick Finished Plywood Panel	\$345.79

Molding

Model #	Item	Price
EW-RCM8	Primary White Shaker Royal Crown Molding	\$157.06
EW-OCM8	Primary White Shaker Outside Corner Molding	\$27.71
EW-SHOE	Primary White Shaker Shoe Molding	\$22.44
EW-SCM8	Primary White Shaker Shaker Crown Molding	\$73.92
EW-BCM8	Primary White Shaker Large Crown Molding	\$150.91
EW-BEM8	Primary White Shaker Bottom Edge Molding (Narrow Light Rail)	\$75.24
EW-BAM8	Primary White Shaker Batten Molding	\$22.01
EW-FBM8	Primary White Shaker Furniture Base Molding	\$103.82
EW-CM8	Primary White Shaker Traditional Crown Molding	\$73.92
EW-COM8	Primary White Shaker Cove Crown Molding	\$123.64

Blind door

Model #	Item	Price
EW-BB36	Primary White Shaker Blind Base Cab for 36" to 39" Space - 30" W	\$363.38
EW-BB42	Primary White Shaker Blind Base Cab for 42" to 45" Space - 36" W	\$411.77
EW-BB48	Primary White Shaker Blind Base Cab for 48" to 51" Space - 48" W	\$453.13
EW-BW3636	Primary White Shaker Blind Wall Cabinet - 36" W x 36" H	\$290.79
EW-BW3642	Primary White Shaker Blind Wall Cabinet - 36" W x 42" H	\$365.13
EW-BW3630	Primary White Shaker Blind Wall Cabinet - 36" W x 30" H	\$267.37

Pantry

Model #	Item	Price
EW-P1884	Primary White Shaker Pantry - 18" W x 84" H	\$568.83
EW-P1890	Primary White Shaker Pantry - 18" W x 90" H	\$613.69
EW-P1896	Primary White Shaker Pantry - 18" W x 96" H	\$638.76

Oven

Model #	Item	Price
EW-OC3390	Primary White Shaker Oven Cabinet - 33" W x 90" H	\$922.51
EW-OC3396	Primary White Shaker Oven Cabinet - 33" W x 96" H	\$985.44
EW-OCD337	Primary White Shaker Oven Cabinet Drawer	\$238.88

Deep

Model #	Item	Price
EW-W361824	Primary White Shaker Deep Wall Cabinet - 36" W x 18" H x 24" D	\$254.71
EW-W362424	Primary White Shaker Deep Wall Cabinet - 36" W x 24" H x 24" D	\$296.08

Single door

Model #	Item	Price
EW-W930	Primary White Shaker Single Door Wall Cabinet - 9" W x 30" H	\$109.54
EW-W936	Primary White Shaker Single Door Wall Cabinet - 9" W x 36" H	\$124.06
EW-W942	Primary White Shaker Single Door Wall Cabinet - 9" W x 42" H	\$147.37
EW-W1230	Primary White Shaker Single Door Wall Cabinet - 12" W x 30" H	\$125.83
EW-W1236	Primary White Shaker Single Door Wall Cabinet - 12" W x 36" H	\$141.65
EW-W1242	Primary White Shaker Single Door Wall Cabinet - 12" W x 42" H	\$168.91
EW-W1530	Primary White Shaker Single Door Wall Cabinet - 15" W x 30" H	\$140.77
EW-W1536	Primary White Shaker Single Door Wall Cabinet - 15" W x 36" H	\$162.32
EW-W1542	Primary White Shaker Single Door Wall Cabinet - 15" W x 42" H	\$192.25
EW-W1830	Primary White Shaker Single Door Wall Cabinet - 18" W x 30" H	\$161.45

EW-W1836	Primary White Shaker Single Door Wall Cabinet - 18" W x 36" H	\$183.90
EW-W1842	Primary White Shaker Single Door Wall Cabinet - 18" W x 42" H	\$219.09
EW-W2130	Primary White Shaker Single Door Wall Cabinet - 21" W x 30" H	\$180.37
EW-W2136	Primary White Shaker Single Door Wall Cabinet - 21" W x 36" H	\$205.43
EW-W2142	Primary White Shaker Single Door Wall Cabinet - 21" W x 42" H	\$244.17
EW-VB15	Primary White Shaker Single Door Base Vanity - 15" W x 21" D	\$220.85
EW-VB18	Primary White Shaker Single Door Base Vanity-18"W x 34.5"H x 21"D	\$238.01
EW-B12	Primary White Shaker Single Door Standard Base Cabinet - 12" W	\$217.32
EW-B09	Primary White Shaker Single Door Full Height Base Cabinet - 9" W	\$157.92
EW-B15	Primary White Shaker Single Door Standard Base Cabinet - 15" W	\$237.11
EW-B18	Primary White Shaker Single Door Standard Base Cabinet - 18" W	\$255.61
EW-B21	Primary White Shaker Single Door Standard Base Cabinet - 21" W	\$276.27

Double door

Model #	Item	Price
EW-B24-2	Primary White Shaker Double Door Standard Base Cabinet - 24" W	\$305.29
EW-B27	Primary White Shaker Double Door Standard Base Cabinet - 27" W	\$377.01
EW-B30	Primary White Shaker Double Door Standard Base Cabinet - 30" W	\$387.57
EW-B33	Primary White Shaker Double Door Standard Base Cabinet - 33" W	\$421.00
EW-B36	Primary White Shaker Double Door Standard Base Cabinet - 36" W	\$429.80
EW-V24-2	Primary White Shaker Double Door Vanity - 24" W x 34.5" H x 21"	\$210.71
EW-V27	Primary White Shaker Double Door Vanity - 27" W x 34.5" H x 21"	\$245.93
EW-V30	Primary White Shaker Double Door Vanity - 30" W x 34.5" H x 21"	\$254.71
EW-V33	Primary White Shaker Double Door Vanity - 33" W x 34.5" H x 21"	\$279.80
EW-V36	Primary White Shaker Double Door Vanity - 36" W x 34.5" H x 21"	\$296.95
EW-W2430-2	Primary White Shaker Double Door Wall Cabinet - 24" W x 30" H	\$214.70
EW-W2436-2	Primary White Shaker Double Door Wall Cabinet - 24" W x 36" H	\$250.31
EW-W2442-2	Primary White Shaker Double Door Wall Cabinet - 24" W x 42" H	\$289.01
EW-W2730	Primary White Shaker Double Door Wall Cabinet - 27" W x 30" H	\$239.76
EW-W2736	Primary White Shaker Double Door Wall Cabinet - 27" W x 36" H	\$271.01
EW-W2742	Primary White Shaker Double Door Wall Cabinet - 27" W x 42" H	\$322.01
EW-W3012	Primary White Shaker Double Door Wall Cabinet - 30" W x 12" H	\$112.18
EW-W3015	Primary White Shaker Double Door Wall Cabinet - 30" W x 15" H	\$139.02
EW-W3018	Primary White Shaker Double Door Wall Cabinet - 30" W x 18" H	\$179.49
EW-W3024	Primary White Shaker Double Door Wall Cabinet - 30" W x 24" H	\$219.96
EW-W3030	Primary White Shaker Double Door Wall Cabinet - 30" W x 30" H	\$247.69
EW-W3036	Primary White Shaker Double Door Wall Cabinet - 30" W x 36" H	\$293.42
EW-W3042	Primary White Shaker Double Door Wall Cabinet - 30" W x 42" H	\$348.43
EW-W3315	Primary White Shaker Double Door Wall Cabinet - 33" W x 15" H	\$151.77
EW-W3330	Primary White Shaker Double Door Wall Cabinet - 33" W x 30" H	\$276.27
EW-W3336	Primary White Shaker Double Door Wall Cabinet - 33" W x 36" H	\$315.00
EW-W3342	Primary White Shaker Double Door Wall Cabinet - 33" W x 42" H	\$373.48
EW-W3612	Primary White Shaker Double Door Wall Cabinet - 36" W x 12" H	\$139.02
EW-W3615	Primary White Shaker Double Door Wall Cabinet - 36" W x 15" H	\$155.29
EW-W3618	Primary White Shaker Double Door Wall Cabinet - 36" W x 18" H	\$206.33
EW-W3630	Primary White Shaker Double Door Wall Cabinet - 36" W x 30" H	\$286.40
EW-W3636	Primary White Shaker Double Door Wall Cabinet - 36" W x 36" H	\$336.53
EW-W3642	Primary White Shaker Double Door Wall Cabinet - 36" W x 42" H	\$399.45
EW-W3918	Primary White Shaker Double Door Wall Cabinet - 39" W x 18" H	\$219.96
EW-W3924	Primary White Shaker Double Door Wall Cabinet - 39" W x 24" H	\$264.81
EW-W3624	Primary White Shaker Double Door Wall Cabinet - 36" W x 24" H	\$246.81

Model #	Item	Price
EW-LSB36	Primary White Shaker Lazy Susan Cabinet - 36" W x 24" D	\$777.57

Easy reach

Model #	Item	Price
EW-WER2430	Primary White Shaker Wall Easy Reach Cabinet - 24" W x 24" D x 30" H	\$311.48
EW-WER2436	Primary White Shaker Wall Easy Reach Cabinet - 24" W x 24" D x 36" H	\$330.76
EW-WER2442	Primary White Shaker Wall Easy Reach Cabinet - 24" W x 24" D x 42" H	\$378.76
EW-ER36	Primary White Shaker Easy Reach Base Cabinet - 36" W x 24" D	\$458.39

Drawer base

Model #	Item	Price
EW-DB12-3	Primary White Shaker Drawer Base Cabinet - 12" W	\$328.62
EW-DB15-3	Primary White Shaker Drawer Base Cabinet - 15" W	\$363.38
EW-DB18-3	Primary White Shaker Drawer Base Cabinet - 18" W	\$390.21
EW-DB21-3	Primary White Shaker Drawer Base Cabinet - 21" W	\$417.48
EW-DB24-3	Primary White Shaker Drawer Base Cabinet - 24" W	\$446.08
EW-DB30-3	Primary White Shaker Drawer Base Cabinet - 30" W	\$477.24
EW-VDB12	Primary White Shaker Vanity Drawer Base - 12" W x 34.5" H x 21"	\$322.89
EW-VDB15	Primary White Shaker Vanity Drawer Base - 15" W x 34.5" H x 21"	\$349.29
EW-VDB18	Primary White Shaker Vanity Drawer Base - 18" W x 34.5" H x 21"	\$376.14
EW-VDB21	Primary White Shaker Vanity Drawer Base - 21" W x 34.5" H x 21"	\$421.00
EW-VDB24	Primary White Shaker Vanity Drawer Base - 24" W x 34.5" H x 21"	\$465.88

Wine Rack

Model #	Item	Price
EW-WR3018	Primary White Shaker Wine Rack - 30" W x 18" H x 12" D	\$196.65

Other

Model #	Item	Price
EW-SPRAYCAN	Primary White Shaker Spray Can	\$8.79
EW-TBUNFOOT	Primary White Shaker Bunfoot	\$87.98
EW-TBUNFOOT2	Primary White Shaker Transitional Bunfoot	\$87.98
EW-TKS8	Primary White Shaker Toe Kick	\$18.93
EW-TPOSTP3	Primary White Shaker Turned Post - 3" W x 35.5" H	\$158.36
EW-TPOSTP5	Primary White Shaker Turned Post - 5" W x 35.5" H	\$241.49
EW-TUKIT	Primary White Shaker Touchup Kit	\$40.80
EW-LRM8	Primary White Shaker Traditional Light Rail	\$150.91
EW-SCRIBE	Primary White Shaker Scribe	\$23.75
EW-SHELF1296	Primary White Shaker Shelf - 96" W x 12" D	\$206.33
EW-CORSM	Primary White Shaker Basic Medium Corbel - 10.5" H	\$41.80
EW-CORT	Primary White Shaker Transitional Corbel	\$117.04
EW-CW2430	Primary White Shaker Corner Wall Cabinet - 24" W x 30" H	\$269.24
EW-CW2436	Primary White Shaker Corner Wall Cabinet - 24" W x 36" H	\$302.22
EW-CW2442	Primary White Shaker Corner Wall Cabinet - 24" W x 42" H	\$383.19
EW-CW2736	Primary White Shaker Corner Wall Cabinet - 27" W x 36" H	\$345.35
EW-CW2742	Primary White Shaker Corner Wall Cabinet - 27" W x 42" H	\$410.01
EW-BBP4842	Primary White Shaker Bead Board - 48" W x 42" H x 0.25" D	\$117.04
EW-BCE1596	Primary White Shaker Book Case End - 1.5" W x 96" H x 15" D	\$170.68

