

RTA

CABINET STORE

June 21, 2026

Primary White Shaker Kitchen Cabinets Price List



Sink base

Model #	Item	Price
EW-CSF42	Primary White Shaker Corner Sink Front for 42" Space - 27" W	\$149.37
EW-SB30	Primary White Shaker Sink Base Cabinet - 30" W x 34.5" H	\$268.60
EW-SB33	Primary White Shaker Sink Base Cabinet - 33" W x 34.5" H	\$284.54
EW-SB36	Primary White Shaker Sink Base Cabinet - 36" W x 34.5" H	\$292.28
EW-SB42	Primary White Shaker Sink Base Cabinet w/ CS - 42" W x 34.5" H	\$335.32
EW-VSB36	Primary White Shaker Vanity Sink Base - 36" W x 34.5" H x 21" D	\$401.19
EW-VSB42	Primary White Shaker Vanity Sink Base - 42" W x 34.5" H x 21" D	\$444.24
EW-VSB48	Primary White Shaker Vanity Sink Base - 48" W x 34.5" H x 21" D	\$496.34

Filler

Model #	Item	Price
EW-FF396	Primary White Shaker Fluted Filler - 3" W x 96" H	\$104.17
EW-OLF330	Primary White Shaker Overlay for 3" x 30" Filler	\$36.59
EW-OLF336	Primary White Shaker Overlay for 3" x 36" Filler	\$42.62
EW-OLF342	Primary White Shaker Overlay for 3" x 42" Filler	\$49.06
EW-OLF630	Primary White Shaker Overlay for 6" x 30" Filler	\$73.62
EW-F396	Primary White Shaker Filler - 3" W x 96" H	\$57.68
EW-F696	Primary White Shaker Filler - 6" W x 96" H	\$115.79

End panel

Model #	Item	Price
EW-DWR3	Primary White Shaker Dish Washer End Panel	\$123.98
EW-BPLG4896	Primary White Shaker Back Panel (Long Grain) - 48" W x 96" H x 1/4" Thick	\$203.62
EW-OP3353	Primary White Shaker Oven Cabinet Overlay Panel - 33" W x 55" H	\$152.38
EW-TEP3096	Primary White Shaker Tall End Panel	\$218.24
EW-PSP4896	Primary White Shaker 1/2" Thick Finished Plywood Panel	\$338.36

Melina

Model #	Item	Price
EW-RCM8	Primary White Shaker Royal Crown Molding	\$153.68
EW-OCM8	Primary White Shaker Outside Corner Molding	\$27.12
EW-SHOE	Primary White Shaker Shoe Molding	\$21.96
EW-SCM8	Primary White Shaker Shaker Crown Molding	\$72.33
EW-BCM8	Primary White Shaker Large Crown Molding	\$147.67
EW-BEM8	Primary White Shaker Bottom Edge Molding (Narrow Light Rail)	\$73.62
EW-BAM8	Primary White Shaker Batten Molding	\$21.54
EW-FBM8	Primary White Shaker Furniture Base Molding	\$101.59
EW-CM8	Primary White Shaker Traditional Crown Molding	\$72.33
EW-COM8	Primary White Shaker Cove Crown Molding	\$120.98

Blind door

Model #	Item	Price
EW-BB36	Primary White Shaker Blind Base Cab for 36" to 39" Space - 30" W	\$355.57
EW-BB42	Primary White Shaker Blind Base Cab for 42" to 45" Space - 36" W	\$402.92
EW-BB48	Primary White Shaker Blind Base Cab for 48" to 51" Space - 48" W	\$443.38
EW-BW3636	Primary White Shaker Blind Wall Cabinet - 36" W x 36" H	\$284.54
EW-BW3642	Primary White Shaker Blind Wall Cabinet - 36" W x 42" H	\$357.28
EW-BW3630	Primary White Shaker Blind Wall Cabinet - 36" W x 30" H	\$261.62

Pantry

Model #	Item	Price
EW-P1884	Primary White Shaker Pantry - 18" W x 84" H	\$556.60
EW-P1890	Primary White Shaker Pantry - 18" W x 90" H	\$600.50
EW-P1896	Primary White Shaker Pantry - 18" W x 96" H	\$625.03

Oven

Model #	Item	Price
EW-OC3390	Primary White Shaker Oven Cabinet - 33" W x 90" H	\$902.68
EW-OC3396	Primary White Shaker Oven Cabinet - 33" W x 96" H	\$964.25
EW-OCD337	Primary White Shaker Oven Cabinet Drawer	\$233.74

Deep

Model #	Item	Price
EW-W361824	Primary White Shaker Deep Wall Cabinet - 36" W x 18" H x 24" D	\$249.23
EW-W362424	Primary White Shaker Deep Wall Cabinet - 36" W x 24" H x 24" D	\$289.71

Single door

Model #	Item	Price
EW-W930	Primary White Shaker Single Door Wall Cabinet - 9" W x 30" H	\$107.18
EW-W936	Primary White Shaker Single Door Wall Cabinet - 9" W x 36" H	\$121.40
EW-W942	Primary White Shaker Single Door Wall Cabinet - 9" W x 42" H	\$144.20
EW-W1230	Primary White Shaker Single Door Wall Cabinet - 12" W x 30" H	\$123.12
EW-W1236	Primary White Shaker Single Door Wall Cabinet - 12" W x 36" H	\$138.60
EW-W1242	Primary White Shaker Single Door Wall Cabinet - 12" W x 42" H	\$165.28
EW-W1530	Primary White Shaker Single Door Wall Cabinet - 15" W x 30" H	\$137.74
EW-W1536	Primary White Shaker Single Door Wall Cabinet - 15" W x 36" H	\$158.83
EW-W1542	Primary White Shaker Single Door Wall Cabinet - 15" W x 42" H	\$188.12
EW-W1830	Primary White Shaker Single Door Wall Cabinet - 18" W x 30" H	\$157.98

EW-W1836	Primary White Shaker Single Door Wall Cabinet - 18" W x 36" H	\$179.94
EW-W1842	Primary White Shaker Single Door Wall Cabinet - 18" W x 42" H	\$214.37
EW-W2130	Primary White Shaker Single Door Wall Cabinet - 21" W x 30" H	\$176.49
EW-W2136	Primary White Shaker Single Door Wall Cabinet - 21" W x 36" H	\$201.02
EW-W2142	Primary White Shaker Single Door Wall Cabinet - 21" W x 42" H	\$238.91
EW-VB15	Primary White Shaker Single Door Base Vanity - 15" W x 21" D	\$216.10
EW-VB18	Primary White Shaker Single Door Base Vanity-18"W x 34.5"H x 21"D	\$232.90
EW-B12	Primary White Shaker Single Door Standard Base Cabinet - 12" W	\$212.65
EW-B09	Primary White Shaker Single Door Full Height Base Cabinet - 9" W	\$154.52
EW-B15	Primary White Shaker Single Door Standard Base Cabinet - 15" W	\$232.01
EW-B18	Primary White Shaker Single Door Standard Base Cabinet - 18" W	\$250.11
EW-B21	Primary White Shaker Single Door Standard Base Cabinet - 21" W	\$270.33

Double door

Model #	Item	Price
EW-B24-2	Primary White Shaker Double Door Standard Base Cabinet - 24" W	\$298.73
EW-B27	Primary White Shaker Double Door Standard Base Cabinet - 27" W	\$368.91
EW-B30	Primary White Shaker Double Door Standard Base Cabinet - 30" W	\$379.24
EW-B33	Primary White Shaker Double Door Standard Base Cabinet - 33" W	\$411.94
EW-B36	Primary White Shaker Double Door Standard Base Cabinet - 36" W	\$420.56
EW-V24-2	Primary White Shaker Double Door Vanity - 24" W x 34.5" H x 21"	\$206.18
EW-V27	Primary White Shaker Double Door Vanity - 27" W x 34.5" H x 21"	\$240.64
EW-V30	Primary White Shaker Double Door Vanity - 30" W x 34.5" H x 21"	\$249.23
EW-V33	Primary White Shaker Double Door Vanity - 33" W x 34.5" H x 21"	\$273.78
EW-V36	Primary White Shaker Double Door Vanity - 36" W x 34.5" H x 21"	\$290.56
EW-W2430-2	Primary White Shaker Double Door Wall Cabinet - 24" W x 30" H	\$210.08
EW-W2436-2	Primary White Shaker Double Door Wall Cabinet - 24" W x 36" H	\$244.93
EW-W2442-2	Primary White Shaker Double Door Wall Cabinet - 24" W x 42" H	\$282.80
EW-W2730	Primary White Shaker Double Door Wall Cabinet - 27" W x 30" H	\$234.61
EW-W2736	Primary White Shaker Double Door Wall Cabinet - 27" W x 36" H	\$265.18
EW-W2742	Primary White Shaker Double Door Wall Cabinet - 27" W x 42" H	\$315.08
EW-W3012	Primary White Shaker Double Door Wall Cabinet - 30" W x 12" H	\$109.77
EW-W3015	Primary White Shaker Double Door Wall Cabinet - 30" W x 15" H	\$136.04
EW-W3018	Primary White Shaker Double Door Wall Cabinet - 30" W x 18" H	\$175.63
EW-W3024	Primary White Shaker Double Door Wall Cabinet - 30" W x 24" H	\$215.23
EW-W3030	Primary White Shaker Double Door Wall Cabinet - 30" W x 30" H	\$242.37
EW-W3036	Primary White Shaker Double Door Wall Cabinet - 30" W x 36" H	\$287.12
EW-W3042	Primary White Shaker Double Door Wall Cabinet - 30" W x 42" H	\$340.94
EW-W3315	Primary White Shaker Double Door Wall Cabinet - 33" W x 15" H	\$148.51
EW-W3330	Primary White Shaker Double Door Wall Cabinet - 33" W x 30" H	\$270.33
EW-W3336	Primary White Shaker Double Door Wall Cabinet - 33" W x 36" H	\$308.23
EW-W3342	Primary White Shaker Double Door Wall Cabinet - 33" W x 42" H	\$365.44
EW-W3612	Primary White Shaker Double Door Wall Cabinet - 36" W x 12" H	\$136.04
EW-W3615	Primary White Shaker Double Door Wall Cabinet - 36" W x 15" H	\$151.96
EW-W3618	Primary White Shaker Double Door Wall Cabinet - 36" W x 18" H	\$201.89
EW-W3630	Primary White Shaker Double Door Wall Cabinet - 36" W x 30" H	\$280.24
EW-W3636	Primary White Shaker Double Door Wall Cabinet - 36" W x 36" H	\$329.30
EW-W3642	Primary White Shaker Double Door Wall Cabinet - 36" W x 42" H	\$390.86
EW-W3918	Primary White Shaker Double Door Wall Cabinet - 39" W x 18" H	\$215.23
EW-W3924	Primary White Shaker Double Door Wall Cabinet - 39" W x 24" H	\$259.12
EW-W3624	Primary White Shaker Double Door Wall Cabinet - 36" W x 24" H	\$241.50

Model #	Item	Price
EW-LSB36	Primary White Shaker Lazy Susan Cabinet - 36" W x 24" D	\$760.85

Easy reach

Model #	Item	Price
EW-WER2430	Primary White Shaker Wall Easy Reach Cabinet - 24" W x 24" D x 30" H	\$304.78
EW-WER2436	Primary White Shaker Wall Easy Reach Cabinet - 24" W x 24" D x 36" H	\$323.65
EW-WER2442	Primary White Shaker Wall Easy Reach Cabinet - 24" W x 24" D x 42" H	\$370.61
EW-ER36	Primary White Shaker Easy Reach Base Cabinet - 36" W x 24" D	\$448.54

Drawer base

Model #	Item	Price
EW-DB12-3	Primary White Shaker Drawer Base Cabinet - 12" W	\$321.56
EW-DB15-3	Primary White Shaker Drawer Base Cabinet - 15" W	\$355.57
EW-DB18-3	Primary White Shaker Drawer Base Cabinet - 18" W	\$381.82
EW-DB21-3	Primary White Shaker Drawer Base Cabinet - 21" W	\$408.51
EW-DB24-3	Primary White Shaker Drawer Base Cabinet - 24" W	\$436.48
EW-DB30-3	Primary White Shaker Drawer Base Cabinet - 30" W	\$466.98
EW-VDB12	Primary White Shaker Vanity Drawer Base - 12" W x 34.5" H x 21"	\$315.94
EW-VDB15	Primary White Shaker Vanity Drawer Base - 15" W x 34.5" H x 21"	\$341.78
EW-VDB18	Primary White Shaker Vanity Drawer Base - 18" W x 34.5" H x 21"	\$368.06
EW-VDB21	Primary White Shaker Vanity Drawer Base - 21" W x 34.5" H x 21"	\$411.94
EW-VDB24	Primary White Shaker Vanity Drawer Base - 24" W x 34.5" H x 21"	\$455.86

Wine Rack

Model #	Item	Price
EW-WR3018	Primary White Shaker Wine Rack - 30" W x 18" H x 12" D	\$192.42

Other

Model #	Item	Price
EW-SPRAYCAN	Primary White Shaker Spray Can	\$8.60
EW-TBUNFOOT	Primary White Shaker Bunfoot	\$86.09
EW-TBUNFOOT2	Primary White Shaker Transitional Bunfoot	\$86.09
EW-TKS8	Primary White Shaker Toe Kick	\$18.52
EW-TPOSTP3	Primary White Shaker Turned Post - 3" W x 35.5" H	\$154.96
EW-TPOSTP5	Primary White Shaker Turned Post - 5" W x 35.5" H	\$236.30
EW-TUKIT	Primary White Shaker Touchup Kit	\$39.92
EW-LRM8	Primary White Shaker Traditional Light Rail	\$147.67
EW-SCRIBE	Primary White Shaker Scribe	\$23.24
EW-SHELF1296	Primary White Shaker Shelf - 96" W x 12" D	\$201.89
EW-CORSM	Primary White Shaker Basic Medium Corbel - 10.5" H	\$40.90
EW-CORT	Primary White Shaker Transitional Corbel	\$114.52
EW-CW2430	Primary White Shaker Corner Wall Cabinet - 24" W x 30" H	\$263.45
EW-CW2436	Primary White Shaker Corner Wall Cabinet - 24" W x 36" H	\$295.72
EW-CW2442	Primary White Shaker Corner Wall Cabinet - 24" W x 42" H	\$374.95
EW-CW2736	Primary White Shaker Corner Wall Cabinet - 27" W x 36" H	\$337.93
EW-CW2742	Primary White Shaker Corner Wall Cabinet - 27" W x 42" H	\$401.19
EW-BBP4842	Primary White Shaker Bead Board - 48" W x 42" H x 0.25" D	\$114.52
EW-BCE1596	Primary White Shaker Book Case End - 1.5" W x 96" H x 15" D	\$167.01

